

DYMO[®]
by pelouze[®]

MODEL X2

2 lb Mechanical Postal Scale



USER GUIDE

DYMO by Pelouze Two-Pound Postal Scale

Your new Two-Pound Postal Scale weighs items up to two pounds in 0.5 ounce increments. This User Guide provides instructions for using the scale.

Adjusting the Scale to Zero

Complete the following procedure before using the scale for the first time.

To adjust the scale to zero

1. Place the scale on a firm, flat surface.
2. Press and release the scale platform several times to make sure the platform moves freely.
3. Turn the adjustment knob until the indicator bar aligns with zero on the scale display.

Perform this procedure from time to time to ensure the scale continues to produce accurate readings.

Using the Scale

You can use your scale to determine the weight of an item and to determine the postage amount for an item.

Weighing an Item

Always make sure that the indicator bar is aligned with zero on the scale display before placing an item on the scale platform. If the indicator bar is not aligned correctly, adjust the scale as described in “Adjusting the Scale to Zero”.


To weigh an item

- ◆ Place an item on the scale platform.
The indicator bar points to the weight on the scale display.

Determining Postage

You can use your scale to determine the First-Class Mail postage amount. You can also use your scale, along with a USPS Zone Chart for your ZIP Code location to determine the Express Mail and Priority Mail postage amount for an item.

❗ You can find a USPS Zone Chart for your ZIP Code at your local Post Office or on the USPS Web site, <http://postcalc.usps.gov/zonecharts>.



To find the First-Class Mail postage amount for an item

1. Place an item on the scale platform.

The indicator bar points to a set of postage amounts on the scale display.

2. From this set, find the postage amount for the item according to the shape of the item.

To find the Express Mail or Priority Mail postage amount for an item

1. Weigh an item.

2. Using your USPS Zone Chart, determine the zone number for the ZIP Code that you are mailing to.

3. Using the Express Mail or Priority Mail chart on the scale display, find the postage amount for the item according to the weight of the item and the zone number.

Replacing the Scale Dial

You can replace the dial on your scale whenever the postal rates change. Visit the DYMO Web site, www.dymo.com, to obtain a replacement dial for your scale with the updated postal rates.

Instructions on how to replace your scale dial are included with the replacement dial.

Caring for the Scale

With proper care and handling, your scale will give you years of service. Keep the following in mind when using your scale:

- Your scale works best when operated and stored at normal room temperature. Avoid lengthy exposure to extreme heat or cold.
- Only operate the scale on a stable, vibration free surface.
- Exposure to dust, dirt, moisture, vibration, and air currents can affect the reliability and accuracy of your scale.
- Although this scale is designed to be quite durable, gently place items to be weighed on the platform. Avoid rough treatment, as this may permanently damage the scale and void your warranty.
- You can permanently damage the scale by placing significantly overweight items on the scale platform.
- Avoid shaking, dropping, or otherwise shocking the scale. This is a precision instrument and **MUST BE HANDLED WITH EXTREME CARE.**

Technical Specifications

Capacity	2 pounds
Resolution	0.5 oz.
Units	lb./oz.
Operating Temperature	40° - 104° F (4.5° - 40° C)

For information about our other scale products, visit www.dymo.com. To obtain support, contact Technical Support at (877) 724-8324.

Warranty

Your DYMO® Scale comes with a warranty against defects in materials, design, or workmanship, for one year from the original date of purchase, when used in accordance with all operating instructions. Normal wear and tear is not covered, nor is excessive use, abuse or damage caused by a user either intentionally or accidentally.

EXCEPT AS PROVIDED HEREIN, DYMO MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, AND DYMO SPECIFICALLY EXCLUDES WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. DYMO'S LIABILITY UNDER THIS WARRANTY SHALL BE LIMITED TO REPAIR OR REPLACEMENT OF THE SCALE. DYMO SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER OR NOT FORESEEABLE.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE AND COUNTRY TO COUNTRY.

In the event of a product failure, please visit www.dymo.com/support or contact DYMO Technical Support to obtain a Return Material Authorization (RMA) number and further instructions to return your product.

© 2008 Sanford, L.P. All rights reserved. Revised 09/08.

No part of this document or the software may be reproduced or transmitted in any form or by any means or translated into another language without the prior written consent of Sanford, L.P.

DYMO®

A **NewellRubbermaid** Company

Produced by:
DYMO, Stamford, CT
800-426-7827: www.dymo.com
© 2008 Sanford, L.P.