



















































# RhinoPRO® 3000

# Quick Reference

This Quick Reference gives you an overview of the features and functions of the RhinoPRO 3000 label printer. For detailed information, refer to the *RhinoPRO 3000 User Guide*.

Function Keys	Description
	Toggle power on and off.
	Navigate the label and menus.
	Add new line; select menu option.
	Print label.
	Turn on Caps mode.
	Shift or select alternate key function.
	Delete character to left of cursor.
	Clear current label text & format.
	Add one space in label text.
	Select symbol characters. See Symbol Table.
	Select font size.
	Select language.
	Select box or underline.
	Advance the label tape.
	Select normal, italic, or outline.
	Select units of measure.
	Turn on backlighting.

Printing	Steps	
Single label	1. Enter text and press  .	
Multiple copies of same label	1. Enter text; press  +  .	2. Set # copies; then press  .
 Serialized labels	1. Enter text; then press  .	2. Set increment; then press  .

Hot Keys	Steps					
 Flag	1. Press  and then  .	2. Enter label text, then press  .				
 Fixed-length	1. Press  .	2. Press  or  to set length.	3. Press  .	4. Enter label text; then press  .		
 Vertical	1. Press  .	2. Enter label text; then press  .				
 Panel	1. Press  .	2. Enter # of boxes; press  .	3. Set box length; then press  .	4. Set # of lines and press  .	5. Enter text for each box; press  .	6. Repeat steps 4 and 5.
 Horizontal Wrap	1. Press  .	2. Enter text and press  .				
 Vertical Wrap	1. Press  +  .	2. Enter text and press  .				

## Using the Pre-defined Text Hot Keys

Four Hot Key™ functions access pre-defined text.



A complete list of available text for each Hot Key is included in the *RhinoPRO 3000 Instruction Manual*.

## Symbol Table

<b>A</b>	!	ı	?	¿	.
<b>B</b>	,	'	#	%	&
<b>C</b>	;	"	+	=	*
<b>D</b>	-	:	/	(	)
<b>E</b>	~	\	@	±	½
<b>F</b>	\$	£	¢	\$	¼
<b>G</b>	↓	↑	→	←	—
<b>H</b>					
<b>I</b>					
<b>J</b>					
<b>K</b>					
<b>L</b>					
<b>M</b>					
<b>N</b>					
<b>O</b>					

## Using Memory

To ...	Do this ...
Save a label to memory	1. Press  + . 2. Select location; then press .
Recall a label from memory	1. Press . 2. Select a label; then press .
Clear memory location	1. Press  and select location. 2. Press  + ; then .

## RhinoPRO Industrial Label Cassettes

The following industrial label cassettes are available for the RhinoPro 3000 label printer:

Width	6 mm	9 mm	12 mm	19 mm	Length
White Flexible Nylon	—	—	18758	18759	3,5 m
Yellow Flexible Nylon	—	—	18756	18757	3,5 m
Yellow Vinyl	—	18431	18432	18433	5,5 m
Red Vinyl	—	18434	18435	18436	5,5 m
Orange Vinyl	—	18437	18438	18439	5,5 m
Green Vinyl	—	18440	18441	18442	5,5 m
White Vinyl	—	18443	18444	18445	5,5 m
White Perm Polyester	—	18766	18764	18765	5,5 m
Metal Perm Polyester	—	18760	18761	18762	5,5 m
Clear Perm Polyester	—	18508	—	—	7,0 m
White Heat Shrink Tube	18051	18053	18055	18057	1,5 m
Yellow Heat Shrink Tube	18052	18054	18056	18058	1,5 m
White Non-adhesive Tag	18111	18112	18113	18114	5,5 m
Yellow Non-adhesive Tag	18115	18116	18117	18118	5,5 m



[www.sanford.com](http://www.sanford.com)

Produced by:

DYMO Corp., Stamford CT ©2006  
800-426-7827; [www.dymo.com](http://www.dymo.com)

A Division of Newell Rubbermaid